

Modulating spring-return actuator with emergency control function for adjusting dampers in technical building installations

- · Air damper size up to approx. 2 m²
- Nominal torque 10 Nm
- Nominal voltage AC/DC 24 V
- Control modulating DC (0)2...10 V
- Position feedback DC 2...10 V
- · with 2 integrated auxiliary switches



Technical data

| | |
|-----------|-------|
| lectrical | しんしゅん |
| | |

| Nominal voltage | AC/DC 24 V | |
|-------------------------------------|-------------------------------------|--|
| Nominal voltage frequency | 50/60 Hz | |
| Nominal voltage range | AC 19.228.8 V / DC 21.628.8 V | |
| Power consumption in operation | 3.5 W | |
| Power consumption in rest position | 2.5 W | |
| Power consumption for wire sizing | 5.5 VA | |
| Auxiliary switch | 2 x SPDT, 1 x 10% / 1 x 1190% | |
| Switching capacity auxiliary switch | 1 mA3 (0.5 inductive) A, AC 250 V | |
| Connection supply / control | Cable 1 m, 4 x 0.75 mm ² | |
| Connection auxiliary switch | Cable 1 m, 6 x 0.75 mm ² | |
| Parallel operation | Yes (note the performance data) | |
| Torque motor | Min. 10 Nm | |
| Torque spring return | Min. 10 Nm | |

Functional data

| Connection auxiliary switch | Cable 1 m, 6 x 0.75 mm ² | |
|---|--|--|
| Parallel operation | Yes (note the performance data) | |
| Torque motor | Min. 10 Nm | |
| Torque spring return | Min. 10 Nm | |
| Positioning signal Y | DC 010 V | |
| Positioning signal Y note | Input impedance 100 kΩ | |
| Operating range Y | DC 210 V | |
| Position feedback U | DC 210 V | |
| Position feedback U note | Max. 0.5 mA | |
| Position accuracy | ±5% | |
| Direction of motion motor | Selectable with switch L / R | |
| Direction of motion emergency control | Selectable by mounting L / R | |
| function | | |
| Manual override | By means of hand crank and locking switch | |
| Angle of rotation | Max. 95° | |
| Angle of rotation note | adjustable starting at 33% in 2.5% steps (with | |
| | mechanical end stop) | |
| Running time motor | 150 s / 90° | |
| Running time emergency control position | <20 s / 90° | |
| Running time emergency setting position | <20 s @ -2050°C / <60 s @ -30°C | |
| note | | |
| Sound power level motor | 40 dB(A) | |
| Spindle driver | Universal spindle clamp 1025.4 mm | |
| Position indication | Mechanical | |
| Service life | Min. 60,000 emergency positions | |
| | | |

Safety

| opinion direct | 5 5 | |
|--|---|--|
| Position indication | Mechanical | |
| Service life | Min. 60,000 emergency positions | |
| Protection class IEC/EN | III Safety extra-low voltage | |
| Protection class UL | UL Class 2 Supply | |
| Protection class auxiliary switch IEC/EN | II Protective insulated | |
| Degree of protection IEC/EN | IP54 | |
| Degree of protection NEMA/UL | NEMA 2, UL Enclosure Type 2 | |
| EMC | CE according to 2014/30/EU | |
| Low voltage directive | CE according to 2014/35/EU | |
| Certification IEC/EN | IEC/EN 60730-1 and IEC/EN 60730-2-14 | |
| Certification UL | cULus according to UL 60730-1A, UL 60730-2- 14 and CAN/CSA E60730-1:02 | |
| Mode of operation | Type 1.AA.B | |
| Rated impulse voltage supply / control | 0.8 kV | |
| Rated impulse voltage auxiliary switch | 2.5 kV | |
| Control pollution degree | 3 | |
| Ambient temperature | -3050°C | |
| · · · · · · · · · · · · · · · · · · · | | |

Spring-return actuator, modulating, AC/DC 24 V, 10 Nm, with 2 integrated auxiliary switches



Technical data Safety Non-operating temperature A-0...80°C Ambient humidity 95% r.h., non-condensing Maintenance Maintenance-free

Weight

Safety notes



Weight

 The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.

2.3 kg

- Outdoor application: only possible in case that no (sea)water, snow, ice, insolation
 or aggressive gases interfere directly with the actuator and that is ensured that the
 ambient conditions remain at any time within the thresholds according to the data
 sheet.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · Cables must not be removed from the device.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed
 of as household refuse. All locally valid regulations and requirements must be
 observed.

Product features

Mode of operation The actuator is connected with a standard modulating signal of DC 0 ... 10 V and

moves the damper to the operating position at the same time as tensioning the return spring. The damper is turned back to the emergency position by spring force when the

supply voltage is interrupted.

Simple direct mounting Simple direct mounting on the damper spindle with an universal spindle clamp,

supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override By using the hand crank the damper can be actuated manually and engaged with the

locking switch at any position. Unlocking is carried out manually or automatically by

applying the operating voltage.

High functional reliability The actuator is overload protected, requires no limit switches and automatically stops

when the end stop is reached.

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops.

Flexible signalization The actuator has one auxiliary switch with a fixed setting and one adjustable auxiliary

switch. They permit a 10% or 11...90% angle of rotation to be signaled.

Accessories

Description **Type Flectrical accessories** S2A-F Auxiliary switch, 2 x SPDT Feedback potentiometer, 200 Ohm, incl. installation accessories P200A-F Feedback potentiometer 1 kOhm, incl. installation accessories P1000A-F Signal converter voltage/current, supply AC/DC 24V **Z-UIC** Digital position indicator for front-panel mounting, 0...99%, front mass ZAD24 72 x 72 mm Range controller for wall mounting, adjustable electron. Min./max. SBG24 angle of rotation limitation SGA24 Positioner for wall mounting, range 0...100% Positioner in a conduit box, range 0...100% SGE24 Positioner for front-panel mounting, range 0...100% SGF24 Positioner for wall mounting, range 0...100% CRP24-B1

Spring-return actuator, modulating, AC/DC 24 V, 10 Nm, with 2 integrated auxiliary switches



Accessories

| Description | Туре | |
|---|------------|--|
| Shaft extension 250 mm, for damper spindles Ø 825 mm | AV8-25 | |
| End stop indicator for NFA / SFA | IND-AFB | |
| Spindle clamp set for NFA/SFA (1", 3/4", 1/2") | K7-2 | |
| Straight ball joint with M8, suitable for damper crank arms KH8 | KG10A | |
| Angled ball joint with M8, suitable for damper crank arms KH8 | KG8 | |
| Damper crank arm, for damper spindles | KH8 | |
| Damper crank arm for NFA / SFA, for 3/4" spindles | KH-AFB | |
| Form fit insert 10x10 mm, for spring return actuators NG | ZF10-NSA-F | |
| Form fit insert 12x12 mm, for spring return actuators NG | ZF12-NSA-F | |
| Form fit insert 16x16 mm, for spring return actuators NG | ZF16-NSA-F | |
| Damper crank arm, for spring return actuators NG | ZG-AFB | |
| Base plate extensions for NFA/SFA | Z-SF | |

Electrical installation




Notes


Mechanical accessories

- · Connection via safety isolating transformer.
- Parallel connection of other actuators possible. Observe the performance data.

Wiring diagrams

AC/DC 24 V, modulating





Cable colours:

1 = black

2 = red3 = white

5 = orange

S1 = violet

S2 = red

S3 = white

S4 = orange


S5 = pink

S6 = grey



Operating controls and indicators

Auxiliary switch settings





Note

Perform settings on the actuator only in deenergised state.

1 Manual override

Turn the hand crank until the desired switching position is set.

2 Spindle clamp

Edge line (A) displays the desired switching position of the actuator on the scale.

3 Fasten the locking device

Turn the locking switch to the "Locked padlock" symbol.

4 Auxiliary switch

Turn rotary knob until the notch points to the arrow symbol.

5 Unlock the locking device

Turn the locking switch to the "Unlocked padlock" symbol or unlock with the hand crank.

6 Cable


Connect continuity tester to S4 + S5 or to S4 + S6.

Manual override


Turn the hand crank until the desired switching position is set and check whether the continuity tester shows the switching point.

Dimensions [mm]

Spindle length



Clamping range



Dimensional drawings

